

# Tuning Instructions for HOMECAST

1. Press Menu on your remote control
2. Press down "▼" to highlight "Installation" and press "OK"
3. Enter password "0000" from the remote
4. Press down "▼" to highlight "Scan transponder" and press "OK"
5. Press down "▼" to highlight "Frequency".
6. Press left "◀" to delete all digits
7. Enter "12706" in frequency from the remote
8. Press down "▼" to highlight "Symbol rate"-22500(if it is some other number, Press the left "◀" and delete the digits, then type in 22500)
9. Press down "▼" to highlight "Polarity" It should be - Vertical. If it is "Horizontal" press "◀" to change it to "Vertical"
10. Press down "▼" to highlight "Code Rate"- 3/4 .If it is 2/3 press "◀" to change it to 3/4
11. Press down "▼" to highlight "Network Search" and change to "Enable" pressing "◀"
12. Press OK and let it scan. The receiver will scan for channels. Press "ok" to save this new list on getting the message" Do you want to save channels"
13. Exit thrice and go Colors channel