

Tuning Instructions for DREAMAX

1. Press Menu on your remote control
2. Press down “▼” to highlight “Installation” and press “OK”
3. Press down “▼” to highlight Manual Scan and press “OK”
4. Enter password “0000” from the remote
5. Press “▼” to go to TP frequency
6. Press OK on the frequency and highlight 12545, then press OK. if this freq is missing follow steps A, B, C, and D
7. Polarisation – Vertical
Symbol rate- 22500
Scan Mode - All
Network Search – On (if it is off, press right arrow key and make it “ON”)
8. Press Red button (LANG) on the remote for scanning the channels
9. “Please wait to save data” will appear. Wait for information to be saved.
10. Press Exit once that message goes off
11. Exit Out of the menu to go to Vision Asia Channels.
12. Change channels till you come to Vision Asia Channels

A) Press GREEN (SOUND) button.

B) Press “OK” for option “ADD” and press the numbers 12706

C) Press “▼” to go to Polarisation and press “▶” to change the option to “Vertical”.

D) Press “▼” to go to Symbol rate and press the numbers 22500

Scan Mode - All

Network Search – On (if it is off, press right arrow key and make it “ON”

PLEASE Continue form step 8