

Sonic / Homecast Tuning Instructions

1. Press Menu
2. Press OK on Installation
3. Enter Pin 0000
4. Press OK on Dish Settings
5. Dish - Press right arrow key and select Optus D2 / Optus B3 Press OK
6. Press Down on Satellite Press right arrow key and Select Optus D2/ Optus B3 Press OK
7. Press Down on Transponder Press right arrow and Select 12706 V 22500 Press OK

*IF NOT then press down arrow key and GoTo New TS

*Frequency: Press number 12706 from remote control then Press OK

*Polarity : Vertical If not vertical press \square and change it

*Symbol Rate :Press number 22500 from remote control then Press OK

*FEC: $\frac{3}{4}$ if not then Press \square and change to $\frac{3}{4}$

8. Press OK

9. LNB Power 13/18V

10. LNB Type 10700/11300

*If not 10700 / 11300 then Press \square and Goto User Single and Press OK

*Enter 10700 / 11300 from your remote and Press OK

11. 22 KHz Off

12. Switch Type None

13. Press EXIT

14. GO to Manual Channel Search

15. Check if the Dish, Freq, Polarity, Symbol Rate are as same as the above steps if NOT then follow the above steps

16. Scan Mode should be All Channels

17. Network Search should be Enable if not then press \square and select Enable

18. PID Search AUTO PID

19. PRESS OK to Start SCAN

20. Scroll the channles and look for ZOOM

